

# TECHNICAL DATA

## Pasa-Jell™ 107 and 107-M



### Description

Pasa-Jell™ 107 and 107-M are blends of mineral acids, activators, and inhibitors. Pasa-Jell™ 107 is inorganically thickened to permit application in localized areas. Pasa-Jell™ 107-M does not contain the inorganic thickener permitting immersion of large surfaces. Pasa-Jell™ 107 is designed to provide a balanced ratio of components which will maintain the effectiveness of the etch rate and inhibit embrittlement as long as the total acid content is maintained above 20%.

Improvement of bond strength is based on surface activation which provides a receptive surface for adhesion.

Pasa-Jell™ 107 and Pasa-Jell™ 107-M chemically clean and activate the titanium alloy surface to provide improved chemical bonding of the adhesive. Pasa-Jell™ 107 and Pasa-Jell™ 107-M leave a clean surface with no trace of residual smut.

Pasa-Jell™ 107 and Pasa-Jell™ 107-M are formulated specifically for titanium alloys.

The etch life of Pasa-Jell™ 107-M is approximately 500 to 1,000 square feet of surface per gallon.

### Use

To improve the metal bond adhesions of titanium alloy.

### Physical properties (typical)

Color	Red
Weight per quart	
Pasa-Jell™ 107	3 lbs.
Pasa-Jell™ 107-M	3 lbs.
Consistency	
Pasa-Jell™ 107	Thixotropic gel
Pasa-Jell™ 107-M	Liquid

### Purchasing data

Product designation: When ordering this product designate Pasa-Jell™ 107 or Pasa-Jell™ 107-M.

### Standard packaging

Designation	Container
Quart	Plastic bottle

### Shipping classification

Corrosive Liquid, N.O.S. UN 3264.

### Special shipping instructions

Class 8 - Corrosive label required.

### Application

For optimum results, the titanium alloy surface should be degreased using a solvent, followed by either a wet or, preferably, a dry blast with fine grit of 250 or 320 aluminum oxide to remove all corrosion products and to condition the metal surface before applying the Pasa-Jell™ product. Where blasting is not practical, the surface should be sanded lightly with aluminum oxide coated abrasives. Satisfactory results may be obtained with the use of alkaline cleaners.

Apply a layer of Pasa-Jell™ 107 to localized areas with a polyethelene, polypropylene or fluorocarbon bristle brush immediately following the abrasive treatment and allow it to stand for about 10 to 15 minutes. The Pasa-Jell™ product should then be rinsed off with cool tap water and allowed to dry at room temperature.

For immersion treatment of titanium alloy skins, use Pasa-Jell™ 107-M in tanks.

**Note:** Tank linings for Pasa-Jell™ products should be made of polyethylene or unplasticized polyvinyl chloride.

The etch rate of a tank solution of Pasa-Jell™ 107-M will depend on the metal pre-treatment. The etch rate will be considerably faster and more uniform on an aluminum oxide blasted surface due to greater surface activity.

It is important that the part and the Pasa-Jell™ 107-M tank solution be held below a temperature of 100° F. This also applies to any tap water rinsing. Treated parts should be dried with cool air prior to priming.

# Pasa-Jell™ 107 and 107-M



The time limit for the application of the primer after rinsing should be held to a minimum, and preferably not in excess of one hour because there is a decay rate of the surface activity. Maximum benefit can be derived by priming the surface soon after the Pasa-Jell™ treatment.

In the event detergent cleaning and acid pickling are employed prior to the Pasa-Jell™ treatment, the following precautions should be observed:

- Make sure the titanium alloy skin is clean before heat treatment.
- Seizure of detergent solution on titanium alloy surface should be avoided. Prevent the part being cleaned from drying. A high-pressure spray rinse is recommended immediately upon removing the part from the detergent tank.
- Check each part as it is removed from the acid pickle solution to make sure a uniform etch has been obtained. If non-uniformity of etch is observed, immerse the part for a longer time period or repeat the entire cycle. Rheology of stretch formed metal may require a longer or more vigorous etching prior to the Pasa-Jell™ treatment.
- Should it be necessary to recycle the part after the Pasa-Jell™ 107 treatment, first immerse it in a nitric-hydrofluoric acid pickle solution and then repeat the above steps.

## Storage

Pasa-Jell™ 107 and 107-M have a storage life of one year without significant loss of activity when stored in a cool, dry area in the original, unopened containers

## Safety precautions

Danger: Extremely hazardous liquid and vapors.

Avoid contact with skin, eyes, and clothing.

Causes irritation to skin, eyes, nose, and throat.

Avoid breathing vapors. Store in a cool, dry area in tightly closed containers.

Pasa-Jell™ 107 and 107-M have been proven to be a safe material to handle when safety and handling precautions are followed. Avoid contact with skin and clothing. Wear rubber gloves, a face shield, and respiratory protection. Avoid breathing vapors. Always work in a well ventilated area. For complete health and safety information, consult the material safety data sheet.

In case of contact, immediately wash skin with large quantities of soap and water. Flush eyes with large quantities of water for 15 minutes or more. Remove all contaminated clothing and shoes. First aid may be required and a physician should be consulted.

If swallowed, give no emetic. Call a physician immediately. Give large quantities of water at once.

For chemical burns, wash the affected area with large quantities of water. Make sure all the adhering chemical is removed.

## Health Precautions

This product is safe to use and apply when recommended precautions are followed. Before using this product, read and understand the Safety Data Sheet (SDS), which provides information on health, physical and environmental hazards, handling precautions and first aid recommendations. An SDS is available on request. Avoid overexposure. Obtain medical care in case of extreme overexposure.

**For industrial use only. Keep away from children.**

**For sales and ordering information**  
[support@pasajell.com](mailto:support@pasajell.com)

**1-833-PASA-JEL (833-727-2535)**

Pasa-Jell is a trademark of Pasa-Jell Inc. with the U.S. Patent Office.

Unique Entity ID: PRG2KSBMHXP5 ● CAGE Code 0XQP4

All recommendations, statements, and technical data contained herein are based on tests we believe to be reliable and correct, but accuracy and completeness of said tests are not guaranteed and are not to be construed as a warranty, either expressed or implied. User shall rely on his own information and tests to determine suitability of the product for the intended use and assumes all risks and liability resulting from his use of the product. Seller's and manufacturer's sole responsibility shall be to replace that portion of the product of this manufacturer which proves to be defective. Neither seller nor manufacturer shall be liable to the buyer or any third person for any injury, loss, or damage directly or indirectly resulting from use of, or inability to use, the product. Recommendations or statements other than those contained in a written agreement signed by an officer of the manufacturer shall not be binding upon the manufacturer or seller.

Printed in the U.S.A

Pasa-Jell, Inc.  
6231 Maywood Avenue  
Huntington Park, CA 90255  
United States of America

1-833-PASA-JEL (833-727-2535)  
[support@pasajell.com](mailto:support@pasajell.com)

Issue Date: 01/24  
Supersedes: 02/14